

# Rodenhouse

5120 West River Dr. N.E.  
Comstock Park Mi. 49321

Door & Window Inc.

Tel: (616-784-3365)  
Fax: (616-784-7663)

[www.rodenhouse-door-window.com](http://www.rodenhouse-door-window.com)

## Guideline for Measuring Patio Screen Doors

- First: Measure the height from the top edge of the bottom track, to the inside of the top pocket. Then deduct  $3/16$ " off of your measurement to allow the new patio screen to load into the pocket and clear the bottom track.
- Second: Measure from the jamb (where the door stops when closed) to the leading edge of the inactive glass door. This dimension plus 2" is the width for the new patio screen.

Note: This method is strictly a guideline on how to measure for a replacement patio screen, as all patio doors are different.

